

Bosch Dishwasher Error Codes: Quick Reference Guide

DIY-fixable error codes

- E22 - Filter blocked: remove triple filter, rinse under running water, reinstall
- E25 - Pump blocked: remove filter, clear debris from pump impeller with pliers
- E15 - Water in base: tilt unit forward 45 degrees to drain base, reset

Error codes that need a technician

- E09 - Heating element failure: professional replacement required
- E24 - Persistent drain fault after cleaning: pump motor failure
- E19 - Diverter motor error: spray arm water routing failure
- E27 - Supply voltage issue: check outlet, may need electrician
- E17 - Water too hot: turn down water heater to 120F and retest

Monthly maintenance checklist

- Clean triple filter system (twist counterclockwise, rinse, reinstall)
- Run dishwasher cleaner tablet once monthly
- Wipe door gasket dry after last cycle of the day
- Check door gasket for cracks or hardening
- Clean spray arm nozzles with a toothpick if water pressure seems low

Repair cost guide (Miami area, 2026)

- Service call: \$60-90 (applied to repair)
- Drain pump replacement: \$130-190
- Heating element: \$130-200
- Control module / diverter motor: \$200-350
- Door gasket replacement: \$80-140

Disclaimer

This guide is for general information only. Costs and repair procedures vary by model. Max Appliance Repair Miami is not liable for outcomes from actions taken based on this content. Consult a licensed technician for your specific appliance model.